



Installation Instructions

1. Disconnect the vehicle's negative battery terminal.
2. Mount Cattle Call Remote unit in a convenient location in the cab.
3. Connect the black wire to the negative battery terminal or vehicle chassis, this provides the ground connection.
4. Connect the red wire to the output side of a 20 AMP fuse, this provides the +12V power connection.
5. Connect the white wire to the positive side of the device to be remote controlled (siren or horn), this provides the +12V power from the Cattle Call Remote.
6. Connect the communication cable to the BASE walkie-talkie's head phone jack.
7. Reconnect the vehicle's negative battery terminal.

Operation Instructions

1. Turn on both walkie talkies and select the same channel for both.
2. Press the microphone button on the REMOTE walkie-talkie.
3. The BASE walkie talkie will sense this action and activate the Cattle Call Remote box.
4. The Cattle Call Remote box will remain activated until the microphone button is released.
5. The toggle switch has momentary-off-on capability.

